



Installation Information

Item #P0757 32" Round Shower Enclosure (3/4" OD)

Includes a 12" wall support and a 36" ceiling support (1/2" OD)

Note: *Two people are needed for assembly.*

1. Take one of the halves of the shower ring and insert the wall tee in one end and the ceiling tee in the other. Be certain that the threaded hole of the wall tee is facing the outside of the ring and that the threaded hole on the ceiling tee is facing upward from the top of the ring. Insert screws and tighten.
2. Take the other half of the shower ring and slip the free ends over the previously installed tees. Insert screws and tighten.
3. After measuring the proper length that the wall and ceiling braces need to be, cut these pieces off at the unthreaded end to the desired length. **DO NOT TAKE THE THREADED PORTIONS OF THE BRACES INTO ACCOUNT WHEN MEASURING THE BRACES.**
4. Install the escutcheons onto the wall and ceiling in their proper positions.
5. Very carefully screw ceiling braces firmly into the ceiling tee. Take care not to flex this joint a great deal. As you then install the ceiling braces into the ceiling escutcheon and tighten the screw, someone must hold steadily the other end of the shower ring to reduce flex.
6. Very carefully screw the wall brace firmly into the wall tee and do not allow the joint to flex. You may now adjust the wall tee to the desired height on the riser. Install the wall brace into the wall escutcheon and tighten the screw.

