Strom Plumbing
BY
Sign of the Crab

Ph: (916) 638-2722 / Fax: (916) 638-2725

Installation Information

ITEM # P0616 Overflow Brackets (Shown with P0679 Supports)

1. **Slide the two overflow brackets onto the 1 ½" overflow tube of drain assembly. Do not fully tighten set screws.**
2. **Measure the length of the support brace needed to connect from overflow tube to supply pipe. This support can be cut down by cutting the non-threaded end only.**
3. **Once support is cut to proper length, thread into the bracket and then attach the clamp to the unthreaded end of the support.**
4. **Position the supports to the width of the supply pipes and attach the other side of the clamp.**
5. **Tighten all set screws.**

