Strom Plumbing
BY
Sign of the Crab

Ph: (916) 638-2722 / Fax: (916) 638-2725

Installation Information

Item #P1021
Wall Mount Shower Enclosure Unit

Warranted only if installed by a qualified licensed plumber. Use Teflon tape on all threaded connections.

Step 1: Installation of Faucet – P0400 faucet with Wall Couplers

1. Shut off the water supply to the fixture before installation.
2. Rough in ½" IPS male pipe, ½" past the finished wall, with 3 3/8" centers.



3. Thread on the wall mount couplers. Insert the screen washer into the nut of the coupler.
4. Attach the faucet body to the wall mount couplers and tighten nuts to secure.
5. Attach the spout and tighten the hold down nut to hold in place.
6. Attach the handles with the screws provided.
7. Remove the aerator from the end of the spout and turn on the water supply to flush the hot and cold lines until the water is clear.
8. Make no adjustments to valves or valve stems. They are tested at the factory for optimum performance.

Step 2: Installation of Shower Riser, Enclosure and Shower Head – P0008, P0009 & P0010

9. First slip the wall tee onto the shower riser about 10" below the crook in the riser. Only tighten slightly as later an adjustment will most likely be necessary. Connect portions of the riser with the union nut.
10. Put the riser nut and cone washer onto the end of the riser leaving about ¼" of riser showing at the riser end.
11. Install the riser onto the faucet, making sure that the riser is fully inserted into the female portion of the faucet and thread on the nut to the faucet connection compressing the cone washer.
12. Two people are needed for the remaining steps. Take one of the halves of the shower ring and slip it onto the wall tee. Be certain that the threaded hole is towards the outside of the ring. Insert screws and tighten.
13. Take the ceiling tee and slip the free ends of the shower ring over this part. Be certain that the threaded hole is towards the top of the ring.
14. After measuring the proper length that the wall and ceiling braces need to be, cut these pieces off at the unthreaded end to the desired length. DO NOT TAKE THE THREADED PORTIONS OF THE BRACES INTO ACCOUNT WHEN MEASURING THE BRACES.
15. Install the escutcheons onto the wall and ceiling in their proper positions.
16. Very carefully screw ceiling braces firmly into the ceiling tee. Take care not to flex this joint a great deal. As you then install the ceiling braces into the ceiling escutcheon and tighten the screw, someone must hold steadily the other end of the shower ring to reduce flex.
17. Very carefully screw the wall brace firmly into the wall tee and do not allow the joint to flex. You may now adjust the wall tee to the desired height on the riser. Install the wall brace into the wall escutcheon and tighten the screw.
18. Thread on your shower head to the riser using Teflon tape on thread.