



## Installation Information

### Item #P0895 – Thermostatic Faucet and Side Mount Shower Enclosure Set

Warranted only if installed by a qualified licensed plumber. Use Teflon tape on all threaded connections.

#### Step 1 – Faucet installation (P0891 Body)

1. Shut off the water supply to the fixture before installation.
2. Connect the shorter threaded ends of the hook-up nipples to the deck mount couplers.
3. Loosely attach the deck mount coupler nuts and screen washers to the faucet.
4. Insert the nipples through the 2 holes in the deck and while holding faucet in place screw the lock down nuts onto the threaded nipples and tighten to secure faucet to deck/tub.
5. Tighten the nuts of the deck mount couplers to the faucet body once positioned correctly on tub.

**This faucet is tested to remain within 1 degree Fahrenheit of your desired setting throughout its operation, with an automatic temperature stop at 104 degrees Fahrenheit. The unit also has a built-in anti-syphon.**

#### Step 2 – Shower Riser, Enclosure and Shower Head – (P0709, P0698 & P0180)

6. First slip the wall tee onto the shower riser about 10" below the crook in the riser. Only tighten slightly as later an adjustment will most likely be necessary. Connect portions of the riser with the union nut.
7. Install the riser onto the faucet, making sure that the riser is fully inserted into the female portion of the faucet.
8. ***Two people are needed for the remaining steps.*** Use the wall tee to connect the two smaller sections together by inserting each side into the sides of the tee. Be certain that the threaded hole on the tee ends up facing toward the outside of the ring to the wall. You will insert the wall support here. Insert the tee screws and tighten.
9. Take the ceiling tees and slip them into the free ends of the smaller sections. Be certain that the threaded hole of the tee is facing toward the ceiling. You will insert the ceiling supports here. Insert the tee screws and tighten.
10. Slide the larger "C" shaped section of the enclosure into the other side of the tees and insert the tee screws and tighten.
11. After measuring the proper length that the wall and ceiling braces need to be, cut these pieces off the unthreaded end to the desired length. **DO NOT TAKE THE THREADED PORTIONS OF THE BRACES INTO ACCOUNT WHEN MEASURING THE BRACES.**
12. Install the escutcheons onto the wall and ceiling in their proper positions.
13. Very carefully screw ceiling braces firmly into the ceiling tee. Take care not to flex this joint a great deal. As you then install the ceiling braces into the ceiling escutcheon and tighten the screw, someone must hold steadily the other end of the shower ring to reduce flex.
14. Very carefully screw the wall brace firmly into the wall tee and do not allow the joint to flex. You may now adjust part A to the desired height on the riser. Install the wall brace into the wall escutcheon and tighten the screw.
15. Apply Teflon tape to the threaded top end of the riser and add shower head.